

## SUGGESTED PAINTING TIPS FOR MASTERGRAIN FIBERGLASS DOORS

**Caution:** Preparing to use paints or other hazardous materials always read the manufactures instructions. When using paints or solvents make sure the area is well ventilated and keep away from flames, children, and combustible materials.

### Painting The Door:

- 1) First clean the door with a mild detergent and water. Or use a Tri-Sodium Phosphate solution.
- 2) Rinse very well and allow to dry completely.
- 3) Prime with a high quality well known brand alkyd or acrylic based primer. Allow primer to dry completely.
- 4) Use a high quality acrylic latex house paint. Follow the manufacturers direction for proper application.
- 5) Be sure to use a primer and paint that are compatible. Generally that means to use the same brand of primer and paint.
- 6) Be sure to use high quality exterior grade paints on outside surface and exposed sides/edges as well as top and bottom.

**Note:** Door should be primed and painted within two weeks of installation or exposure to weather. MasterGrain is not responsible for paint finish results, or any failure of the paint.